

ASSEMBLY PLAN MRX/MRV

Steps :

Attention : wear protection work gloves during assembly!

1) Assemble the steel base through a bolt M5x35 with washer

2) Fix the cap with a plastic hammer

3) In case you order plastic bases, insert them on the upright with the plastic hammer

4) Insert the crossbars at the desired height

5) After having inserted the crossbars, bend the flaps in the holes of the upright

6) In order to stiffen the frame, insert the lateral plate according to following rule:

H= 2000 - 2500: n° 2 lateral plates per frame

H= 3000 - 3500: n° 3 lateral plates per frame

H= 4000 - 5000: n° 4 lateral plates per frame

7) Bend the flaps of the lateral plates inside the holes of the upright

